

## Datasheet

Model Number : R-WR62-NF

# Waveguide to Coaxial Adapter

## Right Angle, 11.9~18.0 GHz, WR62 to N-Female

### Specifications

Frequency Range	11.9-18.0 GHz
Waveguide Type	WR62
Flange Type	FBP140 (Cover)
RF Connector	N-Female
Power Handling	100W(CW)
VSWR	1.25 max
Insertion Loss	0.3dB max
Temperature Range	-40°C~+70°C
Material	Copper/Brass
Inside Finishing	Silver Plating
Outside Finishing	Anti-Corrosive Grey Paint
RoHS Status	RoHS Compliant

### Outline Drawings [mm]:

