

## Datasheet

Model Number : R-WR137-NF

# Waveguide to Coaxial Adapter

## Right Angle, 5.38~8.17 GHz, WR137 to N-Female

### Specifications

|                   |                            |
|-------------------|----------------------------|
| Frequency Range   | 5.38-8.17 GHz              |
| Waveguide Type    | WR137                      |
| Flange Type       | FDP70 (Cover)              |
| RF Connector      | N-Female                   |
| VSWR              | 1.2 max                    |
| Insertion Loss    | 0.2dB max                  |
| Material          | Copper                     |
| Inside Finishing  | Silver Plating             |
| Surface Finishing | Anti-Corrosive Black Paint |
| Temperature Range | -40°C~+70°C                |
| RoHS Status       | RoHS Compliant             |

### Outline Drawings [mm]:

